

## GEM WK1



Produttore : General Music

Cod.Art. : 0241

### TASTIERA ARRANGER

WK1 dispone di 460 suoni PCM, inclusi 17 Drumkits, ideali per interpretare qualunque genere musicale; multitimbrica a 16 Parti, con una polifonia massima di 32 note, split programmabile e possibilità di layer tra due suoni, WK1 consente di creare sonorità ricche e moderne. WK1 contiene 2 processori digitali indipendenti: sono disponibili 22 tipi di Riverberi e 22 tipi di Effetti, con il livello regolabile per ciascuna traccia. La sezione Arranger di WK1 offre 96 Styles completamente rinnovati con 4 variazioni ciascuno, composti da 5 tracce (Drums, Bass, Acc.1/2/3), più 8 styles programmabili dall'utente. E' possibile memorizzare in 63 Performances e richiamare istantaneamente qualsiasi programmazione di suoni, effetti, styles, ecc. WK1 è dotata di un pratico sequencer nel quale potrete registrare fino a 7 Song Styles. Il sequencer è compatibile con i diffusissimi Standard MIDI Files tipo 0, 1 e 1+lyrics. L'utilissimo disk drive incorporato consente di salvare songs e performances su normali floppy disks, creando un illimitato archivio di vostre composizioni; inoltre, l'ampio display di WK1 visualizza i testi delle songs perfettamente sincronizzati con la musica, con un piacevole effetto karaoke, rendendo le vostre performances ancora più coinvolgenti. L'efficiente sistema di amplificazione incorporato da 6W+6W riproduce con grande fedeltà la gamma timbrica dei suoni interni.

### Caratteristiche

- Tastiera: 61 tasti con dinamica.
- Polifonia: 32 note max.
- Politimbricità: 16 parti
- Performances: 63 real-time editabili.
- Suoni: 460 suoni PCM, 17 drum kits e 16 suoni Accordion
- Modo operativo: 3 sezioni real-time (Lower, Upper 1, Upper 2). Single, Split (programmabile), Layer

## GEM WK1

- Controlli: Volume, Pitch bend (wheel), Modulation (button), Traspose, Enter, Escape, Tempo/Data, Sound&Style Keypad, Balance ,
- Metronomo, Single Touch Play, Style/Tempo Lock, Play All Song, Lyrics, Floppy disk, Harmony, Melody Off, Performance, Demo
- Pads: 4 pads programmabili.
- Harmony: 8 tipi.
- Effetti Digitali: 22 riverberi + 22 Effetti (modulation/delay/echo)
- Single Touch Play: 960 (10 per style).
- Edit Track: Edit (fino a 16 tracce), On/Off, Volume, Reverb send, Chorus send, Transpose, Detune, Pan, Pedale volume, Damper
- Display: LCD Multifunzione retroilluminato, Visualizzazione dei testi contenuti nelle song
- Styles: 96 styles x 4 variazioni (drums, bass, acc 1, acc 2, acc 3), 8 User style (Programmabili)
- Controlli Styles: Start/stop, Intro, Ending, Fill &lt;&gt;, Fill &lt;&gt;&gt;, Fill &gt;, Key Start/Stop - Continue, Fade, Arrange on/off, Arrange memory, Lower memory, Bass to lowest, 4 tipi di riconoscimento accordi (one finger, fingered 1, fingered 2, free style)
- Sequencer: 7 Song Style, 8 User Song (16 tracks player), Play/Stop, Record, Song Style recording mode (4 tracks)
- Disk Drive: Load, Save, Delete, Format, Utility. Direct from disk, Play all songs, Pre-load, Compatibility: GMX, CD, WK2, WK3, PS1500, PK7, MIDI file 0,1,1+Lyrics
- MIDI: 16 Canali programmabili, Common, Chord, 16 Tracks Local On/Off, External Clock, 8 MIDI set, General MIDI On/Off, MIDI Start/Stop, Channel lock, Dump
- Connessioni: Cuffia, Damper, Volume, MIDI in/out, Stereo Out, Computer Host (PC1,PC2, Mac)
- Amplificazione: 6 W + 6 W; 2 vie; 4 altoparlanti.

Prezzo : €429,00 IVA inclusa (€351,64 esclusa IVA)